

**Template for installation Zmодел solar panels (Art. No. ZM-MS-019) on the layout
Use 0.6-0.7 mm bit for drilling mounting holes**